



The potential use of fast neutrons to perform computed tomographic imaging

J.N. Wilson, IPN Orsay




The first x-ray image



2




Willhelm Röntgen - 1895



x-ray computed tomography






Allan M. Cormack & Godfrey N. Hounsfield Nobel Prize in Medicine 1979




x-ray computed tomography principle












BAM x-ray CT setup

Bundesanstalt für Materialforschung und prüfung, Berlin, Germany





CCD Detection System (2000x2000 pixels)




For a 2D CCD detector arrays, scattering into other pixels is a big issue. Many of the counts in a pixel do not come from direct paths but from scattered paths.















Large Object x-ray CT

LINAC: 500 keV electrons








INSTITUT DE PHYSIQUE NUCLÉAIRE

Mass attenuation coefficients





Thermal neutron imaging facilities



ORPHEE/ISIS (CEA Saclay, France) Helmholtz Zentrum (Berlin, Germany) MLZ (Munich, Germany) PSI (Switzerland)

ESS (Lund, Sweden)

- Complementary to x-ray CT
- High penetration for high-Z materials
- Potential activation of the sample
- No information on isotopic composition
- Attenuation coefficients vary wildly with material type
- High efficiency detection system is difficult to build



Potential applications of Fast Neutron Tomography

- Border/airport security (e.g. detection of explosives in suitcases)
- □ Nuclear Industry: Characterisation of nuclear waste packages
- □ Cultural Heritage: Imaging inside precious artifacts and objects
- Precision quality control for industry
- Non destructive characterization of geological samples (e.g. Metorites)



LICORNE II






H₂ pressure and low control system




Hydrogen gas cells



Experimental Setup



Non-destructive, penetrating probes of sample compositions A new application for directional fast neutrons





IPN Orsay scanning table










Conclusions/Summary

- Fast neutron imaging would be an interesting potential application for IFMIF/DONES
- Look for special <u>niche applications</u> which are complementary to x-ray or thermal neutron CT
- Requires very well collimated neutron beam + fast neutron detection system (e.g. highly segmented 1D or 2D liquid scintillator array)
- Production and ejection of <u>secondary particles</u> (gammas, neutrons) gives important additional information on the object internal structure
- Secondary particles are produced with 14 MeV neutrons mainly via (n,n'γ) and (n,2n) reactions
- Detection of emitted gamma rays will require additional gamma ray array detection system




AVAILABLE FLUXES

lundi 18 avril 2016








x (cm)



Complementarity neutrons/photons



Thermal neutrons


X-rays

Radiograph of an analog camera: by neutrons (top) by X-rays (bottom). While Xrays are attenuated more effectively by heavier materials like metals, neutrons make it possible to image some light materials such as hydrogenous substances with high contrast: in the X-ray image, the metal parts of the photo apparatus are seen clearly, while the neutron radiograph shows details of the plastic parts.



IMAGING APPLICATIONS

lundi 18 avril 2016



Laboratoire d'Archéologie Moléculaire et Structurale



